

How to Clear Memories of Approved Calculators

Casio Calculators – Most Models

To clear the memory. Press **Shift** Press **9** Select (CLR) . Press **3**

Select (**All**). Press **=** Select (**Yes**)

ClassPad – On application menu, tap (**System**) Tap **Init** . From dialog box choose by tapping (**Delete everything, including Add-In applications**). Tap **OK** Confirmation asks if you want to initialize. Press **EXE** ClassPad will restart.

FX-Algebra 2.0,2.0plus - From (Main Menu) go to (System Manager) and Select (F5 Reset). In Reset screen, Select (F4:Initialise).Confirmation message appears, select **EXE** for (Yes). Press **MENU** to return to Main Menu.

FX-100 - Press **Shift** Press **3** Select (**All**). Press **=**

FX-9750 – Press **MENU** Select (**MEM**). Press **EXE** Use ▼ to select (**RESET**). Press **F1** (YES). (MEMORY CLEARED) will show. Press **MENU**

FX-9860 and FX-CG20

From Main Menu select **SYSTEM** mode, Press **F5** (RSET) to show Reset Screen 1. Select & Press **F5** to show Reset Screen 2. **F2** Select & Press

Sharp EL531

To clear the memory. Turn the calculator over. Press the **Reset** button on the left. Use a paper clip.

Canon F-717SGA

To clear all memory values. Press **Shift** **CLR** Select 2 (Clear Memory) **=** **CA**

Mahobe

To clear the memory. **Note:** All the reset buttons need a paper clip.

Scientific (known as the Spyder) - Press the **Reset** button on the back.

DS-750ET - Press the **Reset** button on the back.

DS-950ES - Press the **Reset** button on the back.

DS-742DQ- Press the **Reset** button on the back.

DS-742CQ - No reset sequence as it does not retain any memory when it is turned off. It automatically resets upon power up.

Texas Instruments

TI-30XB - Press the Reset button on the back. 'Memory cleared' will appear.

TI-84Plus – Press **2nd**, Press **+** (Mem), Press **7** (Reset),
Select '**All Memory**', Select (**OK**)

TI –Nspire - All Models (CAS and Non-CAS)

Press **Home**, Select (**My Documents**), when folder open Press **Menu**,
Arrow down to '**Delete All**', Select (**OK**) to clear all.

T189 and Voyage 200 – Press **2nd**, Press **6**, F1 Menu appears,
Select '**All Memory**', Select (**OK**)

Jastek

To clear the memory.

Press the following two buttons: **Shift** **MODE CLR**

Hewlett Packard

HP40gs – Hold down the **ON** button, the **1** button and the **6** button at the same time.

Release **6** then **1** then **ON**. You will get a message on the screen **Memory Clear**

Press **OK**

HP40g – Hold down the **ON** key, the first menu key **□** and the last menu key **□** at the same time.

Release all keys together. You will get a message on the screen **Memory Clear**

Note: The first menu key is the unlabelled one on the far left. The last menu key is the unlabelled one on the far right.

Deskmaster Scientific

Press **Shift** **CLR** **3** (All) **EXE**

Dick Smith Scientific

Press **Shift** **Mode** **3** **=** **AC**

Deli DL-1705

As for **Dick Smith Scientific**

Home & Office E6610

As for **Casio calculators - Most Models**